


CONSOLE POWER CONNECTION




1. Move headrest all the way forward. Between flap and headrest, unzip the zipper completely. Firmly hold headrest under zipper, and pull up and towards the rear of the recliner to release back. Lay the back on the seat.

Warning: There is a wire connecting headrest motor to control box. If your Style in Motion® has the optional lumbar support, there will also be an air-line attached to the back cushion. Slowly lay on the seat, be careful not to damage the wire or hose.



2. Unwrap the console's power wire from the bracket on the side of the console.



3. Insert power wire from the console into bottom hole on the armless side of the chair. Inside the chair, connect power wire from the console to the open Y-Adapter connector. Secure cables and reinstall back.