





# Comfort Recliner Tension Adjustment Instructions




1. First, rotate your recliner counter-clockwise until the recliner is at its tallest height. Next, flip your recliner forward so that it's resting on the front arms.

\*Note: If your recliner was ordered with legs, simply flip it forward so that it's resting on the front arms.



2. Tension adjustment knobs are on the outer bottom corners of the recliner back. See arrows for location of adjustment knobs.



3. To create more opening resistance, turn tension adjustment knobs (refer to arrow) clockwise. To create less opening resistance, turn tension adjustment knobs counter-clockwise. Make sure knobs on both side of the recliner are adjusted equally.